



Priority Service Maintenance Program

PREVENTIVE MAINTENANCE



N-SERIES GAS

Fleet Value

OF QUALITY PARTS AT COMPETITIVE PRICES

**SERVICE INTERVALS TO 120,000 MILES
REPEAT AFTER 120,000 AT 7,500 INTERVALS**

	7,500 Miles/ 12,000 KM	15,000 Miles/ 24,000 KM	22,500 Miles/ 36,000 KM	30,000 Miles/ 48,000 KM	37,500 Miles/ 60,000 KM	45,000 Miles/ 72,000 KM	52,500 Miles/ 84,000 KM	60,000 Miles/ 96,000 KM	67,500 Miles/ 108,000 KM	75,000 Miles/ 120,000 KM	82,500 Miles/ 132,000 KM	90,000 Miles/ 144,000 KM	97,500 Miles/ 156,000 KM	105,000 Miles/ 168,000 KM	112,500 Miles/ 180,000 KM	120,000 Miles/ 192,000 KM
Engine oil	A	A	A	B	A	A	A	B	A	A	A	C	A	A	A	B
Oil filter	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Cooling system service	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Engine coolant	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	R
Air cleaner filter	I/P	I/P	I/P	R	I/P	I/P	I/P	R	I/P	I/P	I/P	R	I/P	I/P	I/P	R
PCV system				I				I				I				I
Spark plugs												R/P				
Spark plug wire												R/P				
Fuel tank, cap and lines				I				I				I				I
Engine accessory drive belts	I	I	I	I	I	I	I	I	I	I	I	R	I	I	I	I
Evaporative control system				I				I				I				I
Shields and underhood insulation	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Air intake system	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Thermostatically controlled engine cooling fan	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Automatic transmission fluid	I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
Rotate tires	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T	R/T
Brake lining and pad for wear	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake drum and rotor for wear and damage	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake electric vacuum pump (NPR-HD)	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake fluid	I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
Brake line and hoses	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Hydraulic unit	I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
Differential gear oil	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	R
Power steering fluid	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	R
Steering wheel free play	I	I	I	I	I	I	I	T	I	I	I	T	I	I	I	T
Steering gear box torque				T				T				T				T
Driveshaft flange torque	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T
Leaf spring u-bolt torque	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T
Wheel nut torque	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T
Kingpin	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Driveshaft lubrication	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Wheel hub bearing grease (front)				R				R				R				R
Accessory drive belt	I	I	I	I	I	I	I	I	I	I	I	R	I	I	I	I
Air conditioner blower filter	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I

ADDITIONAL SERVICES FOR PSMP

Check for DTC with IDSS	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D
Under cab visual inspection	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Interior lighting, horn, wipers switches and controls	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Radio, A/C, heater, warning lights	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Seat belts, shifter, parking brake, pedals	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Lube door hinges	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Windshield washer solvent	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Windshield wiper blades	I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
Cab lighting, mirrors, glass	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Battery terminals (clean, apply grease)	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Rear body doors, hinges, liftgate, body lights	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Refrigeration or other accessory inspection	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Top off all fluids	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I

COMPLIANCE ITEMS

DOT safety kit	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
DEF fluid	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Mud flaps	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Chassis or exterior body damage	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Liftgate repairs	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Internal body repairs	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Refrigeration or other accessory repairs	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Other items from inspection	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I

A=Adjustment • C=Clean • D=Download • I=Inspection • L=Lubrication • R=Replace • R/T=Rotate and Torque • T=Torque

Services shown in red letters reflect additional services provided under the PSMP program that are in addition to the service procedures specified in the vehicle owner's manual.

Record tire tread depth

LF= /32nds LRI= /32nds LRO= /32nds
RF= /32nds RRI= /32nds RRO= /32nds

Record estimated remaining rear brake shoe life

LR lower lining= /32nds
RR lower lining= /32nds

orig. thick = 0.43 inch



Record estimated remaining front brake pad life

LF pads= /32nds
RF pads= /32nds

orig. thick = 0.51 inch

